## Hot tub cover user manual




Model	Product weight (kg)	Packaging dimensions (cm)	Open cover (cm)
Koriks 800 L	8	90x115x20	116x167x10
Koriks 1000 L	12	175x90x20	175x10
Koriks 1100 L	8	175x130x10	175x120x10
Koriks 1200 L	12	180x90x20	180x180x10
Koriks 1500 L/1800 L	14	200x100x10	200x10
Koriks 1600 L	16	180x120x20	180x240x10
Koriks 1650 L	18	206x103x20	206x206x10
Koriks 1700 L	17	200x120x20	200x240x10
Koriks 2300 L	20	245x125x20	240x240x10
Koriks 11000 L	90	350x125x24+340x115x12	350x12

Each of our hot tub models has a specially shaped cover. When the hot tub is not in use, put the cover on to protect it from rain, dirt and sunlight. It is not permitted to sit, stand or walk on the cover! In winter, care must be taken to ensure that the weight of the snow on the cover does not damage it.

When you close the fasteners of the cover (insulated cover), make sure that the locking codes are '00' when closing, as this will make the clamp easier to lock. Once the clamp has been locked, you must change the code as this will ensure that the clamp locks more firmly and that unauthorised persons cannot access the hot tub. The code cannot be changed, which means it will always open with the code '00' and is locked with all other codes. You should also check that there is not too

much slack in the straps of the cover. If there is too much slack, the cover straps may get broken by wind.

<u></u> <u> </u>	CAUTION!	The weight of the snow may damage the cover.
<u> </u>	CAUTION!	Wind can break the cover if the cover clamps are not fastened or poorly fastened.



Hot tub covers have been given a material and production defect warranty for a period of 24 months. The warranty is valid only if the user has read and understood the user and maintenance manual and undertakes to follows it.

Please note! Products designed for commercial use have a different warranty period.

The warranty does not cover discolouration (fading) of the hot tub cover.

Damage caused by extreme events or other weather phenomena is not covered by the warranty.

Normal wear resulting from the use of the product is not covered by the warranty.

The warranty does not cover corrosion damage resulting from the use of chemicals not approved by the manufacturer and from chemical overdoses.

The warranty becomes void if the product is tampered with, repaired without authorisation or not used for its intended purpose.

The warranty becomes void if the product has been stored in the wrong position or in unsuitable conditions.

The warranty is valid if the buyer informs the manufacturer of the defect within a reasonable time (seven days). The buyer must be able to reliably prove where and when the product was purchased and clearly state the nature of the defect.

## Contact

Koriks-Fiiber OÜ

www.koriks.ee

info@koriks.ee

Sooja tn 6, Saue, Harjumaa 76505

Telephone: (+372) 659 6442